

APLS HAZREM- CHEM/BIO BODY BAG**From: \$1,094.48**

SKU: N/A**PRODUCT DESCRIPTION**

APLS Body Guard HazRem is a rugged, disposable absorbent body bag that protects service providers from potentially harmful chemical and biological agents.

The bag's innovative design – thermal seals, finished edges, treated nylon backing, and a heavy duty, fluid-proof zipper – creates a leak-proof inner chamber that protects service providers from bacteria-laden body fluids and chemical and biological agents.

Constructed with a highly absorbent cellulose core that retains over six liters of fluid, APLS Body Guard HazRem is designed to work independently or with a stretcher for staging, storing, and transporting deceased personnel.

APLS Body Guard HazRem features a surface-active agent for odor control and the rugged design lessens the chance of environmental contamination.

PRODUCT INFO

- Leak proof backing and sealed edges
- Fluid-proof and airtight zipper
- Vapor and fluid leak protection
- Contains up to 6.7 liters of blood and bodily fluid
- Eight (8) handles allow for carrying and easy transport
- Complete concealment capability through zippered top
- Surface-active agent for odor control
- Arced zipper path provides convenient access

- Pocket secures patient documents
- Supports 420–450 lbs. (190.51– 204.12 kg), wet or dry
- Compressed vacuum packed

SPECIFICATIONS

- **Finished Product Size:** 36" x 91" (91.44 cm x 231.14 cm)
- **Target Absorbency (H₂O):** 6500 – 6,850 grams (Target = 6850 grams, or 6.7 liters)
- **Weight Capacity:** 420 – 450 lbs. (190.51 – 204.12 kg)
- **Pad Thickness:** 0.125" (0.32 cm)
- **Pad Weight:** 6.6 lbs. (2.99 kg)